

# Aircraft Pushback Procedures

## T1 Bravo West

23 April 2021

Pushback from bay number	Direction aircraft tail faces	To towbar disconnect point (TDP)	Max aircraft wingspan taxiing past the front of the aircraft into bay no. or along taxiway	Max aircraft wingspan taxiing past the rear of the aircraft into bay no. or along taxiway	Procedure and limitations
<b>B22</b> Critical Aircraft A320 B738	East	T0	B763 on Taxilane Quebec B744 into C11 A333 into C11A	B744 on Taxiway Romeo	Pushback tail north turning east onto Taxiway Tango to T0
	South	Q8	A321/B738 into B28 A320/B738 into C7	No aircraft movement behind	Pushback tail west to pushback limit then pull forward Q8 Engine start not permitted prior to reaching engine start position Blocks entry to B22, B24, C1 and C3
	West	T1	B763 on Taxilane Quebec B744 into C11 A333 into C11A	B744 on Taxiway Papa A333 into C12	Pushback tail north turning west onto Taxiway Tango to T1 Blocks entry to C11 and C11A
<b>B24</b> Critical Aircraft A321 B738	East	T0	B763 on Taxilane Quebec B744 into C11 A333 into C11A	B744 on Taxiway Romeo	Pushback tail north turning east onto Taxiway Tango to T0
	South	Q3	A320/B738 into C9 B744 into C11 A333 into C11A	No aircraft movement behind	Pushback tail south to pushback limit then pull forward to Q3 Blocks entry to B28, B30, C7 and C9
	South	Q8	A321/B738 into B28 A320/B738 into C7	No aircraft movement behind	Pushback tail south to pushback limit and Q8 Blocks entry to B22, B24, C1 and C3
<b>B26</b> Critical Aircraft A321 B738	East	T0	B763 on Taxilane Quebec B744 into C11 A333 into C11A	B744 on Taxiway Romeo	Pushback tail north turning east onto Taxiway Tango to T0
	South	Q3	A320/B738 into C9 B744 into C11 A333 into C11A	No aircraft movement behind	Pushback tail south then pull forward to Q3 Blocks entry to B28, B30, C7 and C9
	West	T1	B763 on Taxilane Quebec B744 into C11 A333 into C11A	B744 on Taxiway Papa A333 into C12	Pushback tail north turning west onto Taxiway Tango to T1 Blocks entry to C11 and C11A
<b>B26A</b> Critical Aircraft DH8D	East	T0	B763 on Taxilane Quebec B744 into C11 A333 into C11A	B744 on Taxiway Romeo	Pushback tail north turning east onto Taxiway Tango to T0
	South	Q3	A320/B738 into C9 B744 into C11 A333 into C11A	No aircraft movement behind	Pushback tail south then pull forward to Q3 Blocks entry to B28, B30, C7 and C9
	South	Q7	A321/B738 into B28 A320/B738 into C7	No aircraft movement behind	Pushback tail south to Q7 Blocks entry to B24, B26, B26A and C3
	West	T1	B763 on Taxilane Quebec B744 into C11 A333 into C11A	B744 on Taxiway Papa A333 into C12	Pushback tail north turning west onto Taxiway Tango to T1 Blocks entry to C11 and C11A

Pushback from bay number	Direction aircraft tail faces	To towbar disconnect point (TDP)	Max aircraft wingspan taxiing past the front of the aircraft into bay no. or along taxiway	Max aircraft wingspan taxiing past the rear of the aircraft into bay no. or along taxiway	Procedure and limitations
<b>B28</b> Critical Aircraft A321 B738	East	T0	B763 on Taxilane Quebec B744 into C11 A333 into C11A	B744 on Taxiway Romeo	Pushback tail north turning east onto Taxiway Tango to T0
	South	Q3	A320/B738 into C9 B744 into C11 A333 into C11A	No aircraft movement behind	Pushback tail south then pull forward to Q3 Blocks entry to B28, B30, C7 and C9
	South	Q5	A321/B738 into B30 A320/B738 into C9	No aircraft movement behind	Pushback tail south then pull forward to Q5 Blocks entry to B26, B26A, B28 and C7
	West	T1	B763 on Taxilane Quebec B744 into C11 A333 into C11A	B744 on Taxiway Papa A333 into C12	Pushback tail north turning west onto Taxiway Tango to T1 Blocks entry to C11 and C11A
<b>B30</b> Critical Aircraft A321 B738	East	T0	B763 on Taxilane Quebec B744 into C11 A333 into C11A	B744 on Taxiway Romeo	Pushback tail north turning east onto Taxiway Tango to T0
	South	Q1	B744 into C11	No aircraft movement behind	Pushback tail south then pull forward to Q3 Blocks entry to B30, C7 and C9
	South	Q3	A320/B738 into C9 B744 into C11 A333 into C11A	No aircraft movement behind	Pushback tail south then pull forward to Q3 Blocks entry to B28, B30, C7 and C9
	West	T1	B763 on Taxilane Quebec B744 into C11 A333 into C11A	B744 on Taxiway Papa A333 into C12	Pushback tail north turning west onto Taxiway Tango to T1 Blocks entry to C11 and C11A

**ALTERNATIVE PUSHBACK OPTION FOR ALL BAYS LISTED**

<b>ALL BAYS</b>	East	E4	B744 on Taxiway Quebec	B744 on Taxiway Romeo	Pushback tail north past Taxiway Tango turning east onto Taxiway Echo to E4
-----------------	------	----	------------------------	-----------------------	---

**Notes**

1. Designated Towbar Disconnect Point (TDP) locations are shown on the attached Towbar Disconnect Point Map.
2. Cross bleed start for all aircraft is at E4, T0 and T1.
3. Taxilane Quebec south of Taxiway Tango is restricted to maximum B763 aircraft.
4. Turbo-prop aircraft are to be pushed back on the apron using the first TDP listed for that bay unless otherwise stipulated by ATC.
5. DH8D is the ICAO code for Dash 8 Series 400 aircraft.
6. Aircraft pushback procedures are produced by Airfield Design ([airfieldsupport@melair.com.au](mailto:airfieldsupport@melair.com.au)).